

SERENE
innovations

TV SoundBox®


Model TV-SB

Quick Start Guide

It's as easy as 1,2,3


Connection:

1. Connect the TV-SB to your TV as shown below:




Charging Your TV-SB Before First Use:

1. Place the Receiver on the Base to charge for 8 hours or until the Lo Battery/Charging Indicator stops flashing and turns steadily lit.




Receiver On/Off, Volume and Tone Adjustment:

1. Turn Volume knob to turn the Receiver **ON** or **OFF**.
2. Rotate the Volume knob to adjust volume
3. Select Tone to the setting that gives you the best voice clarity.



Low Battery and Recharging:

1. Place Receiver on its base for recharging when Lo Battery/Charging Indicator flashes or when Receiver is not in use.
2. Charging is complete when the Charging Indicator stops flashing and turns steadily lit.



Need Help? Call Toll-free Help Line:
866-376-9271 (9AM - 5PM PST, M-F)



14731 Carmenita Road, Norwalk, CA 90650
www.sereneinnovations.com

REV 8-1